

*Supra[®]
Vision[™] Control
2019*

Owner's Manual



We continually strive to bring you the highest quality, full-featured products. As a result, you may find that your actual display screens may be slightly different than what was represented in this manual at the time of printing.

Trademarks & Patents

Supra® is a U.S. and Canadian registered trademark owned by Skier's Choice, Inc. and AutoWake® is a U.S. registered trademark owned by Skier's Choice, Inc. Skier's Choice™, the Skier's Choice logo, the Supra logo, SR™, SA™, SE™, Vision™ Control, Swell™ and SmartPlate™ are trademarks owned by Skier's Choice, Inc. All other trademarks are the property of their respective owners.

AutoWake®: U.S. Patent Nos. 8,798,825; 9,689,395; 9,828,075; 9,873,491 and other patents pending.
Amplitude Display: U.S. Patent No. 9,950,771 and other patents pending.
See www.skierschoice.com/patents-trademarks/ for virtual patent marking.

Skier's Choice, Inc. reserves the right to change product specifications at any time without incurring obligation.

©2018 Skier's Choice, Inc. All rights reserved.

Table of Contents

Product Information	4
Care and Maintenance	5
Basic Navigation Features	6
PV450 Quick Access Keys	6
Touch Point Commands.....	7
Menus.....	7
PV1200 Features	7
Home Screen	7
Media.....	10
Maps.....	11
Video	13
AutoWake®	14
ZeroOff GPS Speed Control®	15
PV1100 Features	16
Home Screen	16
Media Settings.....	18
Switches and Lights	29
AutoWake®	31
Rider Profiles.....	40
Maps.....	42
Go Pro	44
Settings.....	48
PV450 Features	60
Home Screen	60
General Troubleshooting Guide	63

Product Information

The Supra® Vision™ Control 2019 displays are designed for instrumentation and control on electronically controlled engines communicating via SAE J1939 and NMEA 2000. The displays enable boat operators to view many different engine, ballast, transmission parameters and service codes and are multi-functional tools that provide GPS tracking, AutoWake®/Surf controls and cruise control. Included with this solution are the PV1100, PV1200 and PV450 Touch units.

PV1100	PV1200	PV450
 The PV1100 is a vertical, rectangular touch display. The screen is black and features the word "SUPRA" in a stylized, glowing white font. The text is centered and flanked by two faint, circular outlines.	 The PV1200 is a horizontal, rectangular touch display. The screen is black and features the word "SUPRA" in a stylized, glowing white font. The text is centered and flanked by two faint, circular outlines.	 The PV450 is a smaller, horizontal, rectangular touch display. The screen is black and features the word "SUPRA" in a stylized, glowing white font. The text is centered and flanked by two faint, circular outlines. To the right of the screen, there are four physical buttons arranged vertically.

Care and Maintenance

General maintenance is not required; however, a soft cloth can be used for cleaning the units. Window cleaner or alcohol can also be used to clean the glass portion of the display. Do not use harsh or abrasive cleaners on the units.

Basic Navigation Features

All product features are easily accessed through Quick Access Keys (only on the PV450), Touch Point commands and Menus.

PV450 Quick Access Keys

A new screen can be accessed quickly by pressing one of the following Quick Access Keys:



Touch Point Commands

Navigation within the screens is controlled by touching the screen's active areas. These areas are illustrated within the following sections specific to each display.

Menus

Menus within the Settings section on the PV1100 allow the system's controls to be customized. This area will be discussed within the PV1100 Settings section.

PV1200 Features

Home Screen

The Home screen will appear after accepting the Acknowledgement of Risk that appears on the PV1100 screen when it is powered on.



Screen Area	Description
Fault Display	Engine or PDM faults will appear in this area. To investigate the cause of the fault, review the Diagnostics utility within Settings on the PV1100.
Time	Displays the local time.
Direction	Displays the current direction in which the boat is traveling.
Media Notifications	Displays the number of missed incoming calls for connected cellular devices.
Water Temperature	Displays the current temperature of the water in which the boat is floating.
Water Depth	Displays the current detected depth of the water.
Media Controls	Displays the currently selected media (i.e., Bluetooth, Wireless Devices or USB) and the selection currently being played.
Maps Display	Displays the GPS-controlled Maps selection.

Screen Area	Description
Video Display	Displays one of two video feeds on the boat (Tower and Transom).
AutoWake Controls	Displays the AutoWake settings for Pitch and Roll, Surf Settings and rider profiles.
ZeroOff On/Off	Turns on and off the ZeroOff GPS Speed Control® system.


Media

In order for the PV1200 to display media contents, the media must be connected on the PV1100. Please see the section within PV1100 titled Bluetooth for instructions on connecting the two devices to a Bluetooth source.

Maps

Similar to Media, Maps will only be displayed on the PV1200, with the Maps controls residing on the PV1100. Please see the section titled PV1100 Maps for instructions on using this utility.

There is one Maps control that resides on the PV1200, that being the expandable screen:





When a larger Maps screen is desired, touch the  symbol, and the two dials will slide to the side, expanding the screen:



The same information from the dials is displayed on the sides of the map, but in a different format. To bring the screen back to what is shown in the top picture, touch the  symbol again.

Video

The video controls that reside on the PV1200 allow you to choose between a view from the Tower or the Transom:



Touch the Tower or Transom button to switch to the alternate video view.

AutoWake®

When AutoWake is enabled and active, the ballast system will be automatically controlled to target and maintain specific boat axes (pitch and roll). Pitch and roll set points are determined by the active rider profile and the currently selected Surf side (Left/Right). Changes to the current Surf side's pitch and roll set points can be saved to the active rider profile or saved to a new profile.

The AutoWake controls reside on the PV1100. Please see the section titled PV1100 AutoWake for additional information. AutoWake®: U.S. Patent Nos. 8,798,825; 9,689,395; 9,828,075; 9,873,491 and other patents pending. See www.skierschoice.com/patents-trademarks/ for virtual patent marking.



2018-08-09

14

180020

ZeroOff GPS Speed Control®

Zero Off is a GPS speed control based solely on input from satellites and engine management systems. It is based on the speed you are traveling across the surface of the water; therefore, there is no requirement for skier weight, crew weight or any kind of wind adjustment. You simply set the desired speed and go. This easy-to-use technology has made Zero Off the industry standard.



Touch the ZeroOff Off button to turn on the GPS speed control. After a few seconds, the Set Speed controls will appear.

Use the + and – buttons to adjust the Set Speed.

To turn off ZeroOff, touch the Off button.

PV1100 Features


Home Screen

While the PV1200 is the flash of the Vision Control, the PV1100 is the function. The majority of the settings will be set and controlled through this display.

The top portion of this screen has three tabs to control Media, Lights and Switches and AutoWake.

The middle portion of this screen houses all of the system's settings, such as Display Settings, GPS Utilities, Ballast, etc.

The lower portion displays the currently selected rider profile, Maps and Camera.



Media Settings



Touching the top tab on the PV1100 display will shift the screen down and this screen will appear.

The first tab shown is **SOURCE**. Media files can be sourced through the following choices:



AM / FM Radio



Both AM and FM Radio sources contain 10 slots to save a preferred station.




Touch **SCAN**,  or  to navigate to the desired station.


Touch and hold an empty slot until that station number appears in the slot and a star appears beside the AM box, as shown below:



Bluetooth




To connect a Bluetooth device, follow these steps:

Step	Action
1	<p>Touch the Bluetooth tab. Previously connected devices will be displayed:</p> 
2	<p>Touch . Directions appear to open the Bluetooth settings on your device, check that Bluetooth is on, and that your device is visible to new devices.</p>

Step	Action
3	The PV1100 will begin to scan for new devices and will display its findings on the screen. Touch the + beside the device to be added.
4	A message will appear stating that a pairing has been requested. On the device, a Bluetooth Pairing Request message will appear. Select Pair.
5	On the PV1100, a message will appear stating Pairing Complete.
6	A second question will appear on the device asking if the PV1100 can have access to the device's contacts. Select either Yes or No.
7	When paired, the PV1100 display will show a check mark beside the connected device.
8	Touch the Source tab again, which now shows BT. The device's music content will be playing on the screen.

Audio Settings



Adjust Equalizer allows the Bass, Mid and Treble sounds to be adjusted to your liking.

Tuner Region allows you to select the region from which the tuner signals will arrive (Australia, Europe, Japan, North America, South America or Taiwan).

Auto Volume Intensity allows the adjustment of the intensity of the volume when it comes on automatically (i.e., to compensate for wind noise, engine noise, etc.).

Audio Zone Preset



There are four Audio Zone Preset settings that can be adjusted to your liking:

1. Ski/Wake
2. Surf
3. Cruise
4. Custom

Touch the  symbol beside one of the four audio zones to mute that area.

Slide your finger along the volume line to adjust the volume for the entire craft.


Touch the  symbol to mute all audio zones.

To adjust the settings within an audio zone, touch the  symbol, and the following screen will appear:



As you can see on the left, the Ski/Wake preset is active.

To edit one of the presets, touch the arrow on the right for that zone.



Use the + or – buttons to adjust the volume for each desired audio zone.


Touch Save when complete.

USB



Another source of media that is acceptable for use is the USB drive. Insert the USB into the PV1100's pigtail and the screen will display the contents of the drive (one song at a time).


NOAA



There are seven pre-programmed NOAA (National Oceanic and Atmospheric Administration) weather channels available on the PV1100.

Simply touch a channel button to listen to that channel.

Auxiliary



The PV1100 also has an auxiliary pigtail that allows 3.5mm connectors to be utilized.

Plug the 3.5mm connector into the pigtail and that device's contents will be displayed on the screen.

Switches and Lights



Switches

Touch the Switches tab and the screen to the left will appear.

The Heater has three settings: Off, Low and HI. Touch the button for the desired setting.

The Seat Heater is turned on in the same manner.

The driver's seat can be moved forward, back, up and down with the directional buttons shown for the seat.

Touch the Blower and Bilge buttons to turn on and off those switches.




Lights

The lights on the boat can be turned on and off by touching their respective buttons shown here.

To turn them all on or off at once, touch All On or All Off.

When the  symbol is beside a light button, that represents a myriad of light colors from which to choose and will display the following:



Touch the desired color to display, and adjust the brightness via the slide bar on the right.



AutoWake* is a patented system that will manipulate the ballast levels in order to achieve and maintain the best possible wake for surfing and wakeboarding. Using an inclinometer (a device that measures angle of pitch and roll) the boat will orient itself for the best boating experience.

*AutoWake®: U.S. Patent Nos. 8,798,825; 9,689,395; 9,828,075; 9,873,491 and other patents pending. See www.skierschoice.com/patents-trademarks/ for virtual patent marking.

The text to the right of the On/Off switch will show one of six current states of the system:

(1) AutoWake Inactive: This will occur when:

- AutoWake is turned off
- Cruise setpoint is below 7mph or above 26mph, or
- When actual speed is below 3mph and within 0.1mph of setpoint.

Below 3mph, AutoWake will use static functionality. Within 0.1mph, AutoWake will use dynamic functionality. The 10 second countdown timer will activate when actual speed is within 0.1 of set speed AND when the boat slows down to less than 3mph. During this state, AutoWake will do nothing.

Once the button is pressed to turn on AutoWake, the system will try to first fill front ballast to establish the correct roll, then it will fill all the rear ballast until rear “Amplitude” is achieved. It does this in Static mode when the boat is traveling less than 3 mph and in Dynamic mode when the speed is within .1 of set speed. If AutoWake is active, achieved or in countdown, it will return to inactive if a ballast switch is used, speed is not between 7 mph and 26 mph, or cruise set speed is not within 7 mph and 26 mph. If the display is powered down, it will come back with AutoWake off.

(2) AutoWake Countdown: Once all conditions are met in the AutoWake Inactive state, a countdown of 10 seconds will begin. This countdown will

remain as long as conditions continue to be met. Once the countdown is finished, AutoWake will become active. If any of the conditions change to be outside of the Active limits, the countdown will stop and the state will go back to AutoWake Inactive. The countdown will start over once conditions are met.

- (3) **AutoWake Active:** This will occur once:
- Set speed is between 7mph and 26mph
 - Actual speed is within 0.1mph of set speed
 - The 10 second countdown has finished.

After the countdown, the AutoWake system will begin to fill and drain ballasts in order to reach the desired pitch and roll values. The system will always fill before it starts to drain. Therefore the side that needs to lower will always fill to 100% before the opposite side begins to drain (to raise that side). For roll, if one side has reached the maximum and the other side has reached the minimum (rear ballasts only), there will be a pop-up that prompts the user to adjust weight in the boat to achieve the desired roll values. The pitch value will have a similar pop-up but will only occur once the roll is finished moving (either achieved or maxed out). When the roll or pitch cannot move, the color of the set points will turn red.

(4) **AutoWake Achieved:** This will occur:

- Once the current pitch and roll values (average value over 5 seconds) are within 0.25 degrees
- AutoWake becomes Active.

The colors of the set points will be green. The achieved status will remain until the pitch or roll is outside of 0.75 degrees of the set point (in which case it will go back to the AutoWake Active state).

(5) **Static AutoWake Active:** This state will occur when:

- Boat is turned on
- AutoWake is turned on
- Actual speed is less than 3mph.

The system will attempt to fill and/or drain ballasts to reach a static pitch, roll and amplitude setpoint. If pitch or roll setpoints cannot be achieved, a pop-up will occur indicating this to the driver (AutoWake will remain in this state).

(6) Static AutoWake Achieved: This will occur when:

- Boat is turned on
- AutoWake is turned on
- Actual speed is less than 3mph
- Pitch, roll and amplitude values match their respective setpoints.

If pitch or roll setpoints cannot be achieved, a pop-up will occur indicating this to the driver and AutoWake will remain in Static AutoWake Active state. If pitch and roll are achieved and amplitude is as close as possible to setpoint, the AutoWake system will go to this state.

AutoWake settings can be found in the Vessel Settings menu.

Changing the Pitch and Roll Set Points

The Pitch and Roll Set Points may be changed via the – and + buttons beside the setpoint values:



Once any value has been changed from the settings in the active rider profile, a yellow dot will appear beside the changed value.



Setting the Wake Amplitude



Use this setting to define the amplitude of your wake (0 is mellow and 100 is aggressive). The Wake Amp* bar will fill (in blue) or empty to the target Wake Amp setting (orange pointer). This blue fill will indicate your total fill level for all ballast.

The Wake Number on the left is used to reference the current calculated weight of your boat (including passengers, gear and ballast). Weight plays a big part in driving the size of your wake. Use the yellow line indicator to determine your current/actual Wake Number position. Use the green line indicator as a reference for the potential Wake Number position (i.e., what could be possible if gear and passenger weight was adjusted).

* Amplitude Display: U.S. Patent No. 9,950,771 and other patents pending. See www.skierschoice.com/patents-trademarks/ for virtual patent marking.

Swell™ Surf and Plates



Swell Surf will only engage when:

- Cruise is on
- Current speed is between 7 mph and 14.5 mph, and
- Set speed is less than 14.5 mph.




Touch a directional Surf icon to select surfing either on the Left or Right.

Adjust the Swell Plates to create the optimum wave. Touch either Swell Port or Swell Stbd (Starboard) and the following will appear:



Utilize the – and + keys to adjust the chosen plate. Touch Save when done, or X to exit without saving the changes.

Ballasts




Ballast is used to add displacement to the craft in order to make the waves or wakes larger for specific watersports.

Touch the up or down arrow to begin filling or emptying the ballast. It will graphically begin filling or draining with water, and the added weight will be shown.

Alternately, touch Fill All or Drain All to fill/drain all three ballast bags at the same time.

Stop All will stop the filling or draining in all ballast bags at the same time.

Rider Profiles




Supra allows the creation and saving of rider profiles in this system. Touch the rider icon  in the lower left corner and the screen at left will display.

Rider profiles that have been prepopulated with various settings exist for you to try out. Follow these steps:

1. Touch a profile name, and then touch .
2. The profile name will then display on the bottom left, and the AutoWake screen will appear.

To edit an existing profile, follow these steps:

1. Make any desired changes to an active profile.
2. At the top of the screen, the New Changes box appears.
3. Touch the Save icon .



4. You may choose to save the changes to the Current Profile, or to a New Profile.
5. When saving to a New Profile, the Create New Profile screen appears for a name to be assigned. Type in the profile name, and touch Done.

To delete an existing profile, follow these steps:

1. Touch the profile name either at the bottom of the screen by the rider profile icon, or from the Rider Profiles screen.



2. Touch

3. A confirmation message will appear to verify the delete. Touch



Maps



The Maps utility can be accessed by touching the Maps



icon at the bottom of the screen. The functions on the GPS are handled through touch points on the screen:



This displays the ability to turn on and off the map's grids, text, waypoints, tracks and navigation aids.



This displays the keyboard to name a new waypoint.



This records the boats movements. When done, touch Stop and the keyboard displays to name the track.




Touching these buttons alternates between North Up and Course Up and will orient the map accordingly.



Zoom Out and Zoom In

You may also touch a part of the screen and drag it to pan to a different part of the map.

Go Pro




Having a GoPro camera onboard allows interesting photos to be taken by people in (or out of) the boat.

Begin by touching Add Device. A list will appear to show previous devices that have been paired with the system.



Note: Be sure to set the camera name and password via the GoPro mobile phone application. Open your camera settings and check that Wireless is on and in RC+APP mode.

Select the device from the list, and enter the GoPro's password when prompted.



If successful, the camera's view point will appear:






Record: use this to record Video.

Capture: use this to capture single photographs.

Burst: use this to capture several shots in a row.


Timed: use this to take a time-lapse series of photos.



use this button to begin and end the photos/video.

The Media button will display all photos and videos in memory:


Back
to
Camera



Refresh
Trash
Selected
Trash
All

Gallery

Settings



The Settings menu contains the following utilities:

- **System Info:** provides the Application, OS, Bootloader and Software information. Also houses the ability to update the software.
- **Display Settings:** controls the brightness, color scheme, etc.
- **Device Manager:** controls the adding of RT Wireless remotes and Bluetooth connected devices.
- **GPS Utilities:** manages the Map utilities and Satellite Status.
- **Ballast:** controls Ballast times and SmartPlate settings.
- **Diagnostics:** provides the Engine and PDM diagnostics.
- **Dealer:** this is a restricted area for Dealers only.
- **Patent Information:** contains the QR code to review the Skier's Choice patent information.

System Info



This screen displays the current version and part numbers for the Application, Operating System, Bootloader and Software used on the display, dash display and PDM software.

To update to a different version of the software, touch

UPDATE SOFTWARE

Plug in a USB with the updated software and touch

Refresh USB List

then follow the instructions shown.

Display Settings



Auto Backlight: this automatically dims the brightness when the Navigation light is on.

Brightness: use the – or + buttons to adjust.


Units: choose US Standard or Metric.

Shutdown Time: use the – or + buttons to adjust the minutes it takes to shutdown the system.

Minimum Depth: use the – or + buttons to adjust the minimum detectable depth in feet.

Color Scheme: the current selection has a checkmark beside it.

Device Manager



RF Wireless Remote

This screen displays the number of wireless devices paired to the system along with the wireless device number and version. It also allows you to pair a wireless device and erase all wireless devices paired to the system.

To pair a new device, touch Pair New Device. The Add New Device screen will appear. Ensure the device is powered on and touch the green check mark. Press any key on the remote to pair the devices.



Bluetooth

The top half of this screen is the same as previously described within Media Settings of the PV1100.

The bottom half of the screen allows you to enable call and text notifications that will appear on the screen when you receive an incoming phone call or text.

Edit Quick Text Replies allows you to choose or edit a prewritten reply to any incoming texts. When a text arrives, touch Edit Quick Text Replies and choose a reply to be automatically sent.

GPS Utilities

Depth and Position:

Within this section there are three subsections:

- 1) **Position Format Selection:** controls how the positions on the map are shown. Choose between Degrees and Decimal Degrees; Degrees, Minutes and Decimal Minutes; or Degrees, Minutes, Seconds and Decimal Seconds
- 2) **Depth Contour:** signifies the depth that will be displayed on the map. Choose between All, 66 ft, 33 ft, 16 ft, 6 ft or Off.
- 3) **Safety Contour:** signifies when an alarm will be displayed if a particular depth is close. Choose between 66 ft, 33 ft, 16 ft, 6 ft or Off.

Waypoint Manager

This section lists all the saved Waypoints from the Map. Select one and choose to View, Edit or Delete that waypoint. Also available is the ability to delete all waypoints.

Chart and Time:

This section allows you to choose if Grids, Text, Waypoints, Tracks and Navigation Aids will be shown on the Map.

This section also provides a way to offset the GMT time by choosing the number of hours difference between GMT and your location.

Lastly, choose between a 12 hour and 24 hour clock display.

Track Manager

This section allows you to view on the map, edit and delete one or all the saved tracks.

Satellite Status

This section shows all the detectable satellites transmitting signals in the boat's area.

Ballast

The first section of this page controls how quickly the ballast fills and drains. Use the – and + buttons to establish the minutes and seconds for the Port, Center and Starboard ballast bags.



The second section of this page concerns the SmartPlate™:

Crossover Point: Set the percent of set speed at which the SmartPlate activates to the position set in the rider profile.


SmartPlate Down: Set the percentage at which the SmartPlate will be tilted down when the speed is less than the crossover point.

SmartPlate Up: Set the percentage at which the SmartPlate will be tilted up when the speed is greater than 15 mph and the cruise is off.

Supra Launch System: enable or disable this system to be used as a launch aid when Swell Surf is turned off.

Ballast Calibration: when the ballast is full or empty and the display is showing that it is not full or empty, the ballast will need to be recalibrated. Touch the appropriate button if the ballast is actually full or empty and it will be calibrated.

Diagnostics



Engine Diagnostics


This screen will display the active and stored faults for the engine. Touch Get Faults to retrieve any stored faults.

This screen also displays the Engine Hours accumulated for the engine.



PDM Diagnostics

This screen provides diagnostics for the Power Display Module. A red light means a short circuit is present. A yellow light means there is an overcurrent. A green light means there are no faults and the circuit is active.




Patent Information

This screen's QR code when scanned will display a webpage to satisfy the virtual patent marking provisions of various jurisdictions.

PV450 Features

Home Screen

The PV450 serves as an additional display/controller for the Audio, Lights and Switches and System Info utilities.



Audio Sources



Like the Audio function within the PV1100, the PV450 allows the various sources to appear. Touch the Source area and choose between AM/FM Radio, Bluetooth, USB, NOAA and Aux.

Touch the  to return to the Main screen.

Lights and Switches



Simply touch a light or switch to turn it on or off.

System Info



Like the System Information screen in the PV100, this screen provides version and part numbers for the Application, Operating System, Bootloader and Software, along with a way to update the software.

General Troubleshooting Guide

Display appears not to work or doesn't come ON.

1. Display could be in *sleep* mode. Touch a key on the keypad to activate the display.
2. Check for loose connections at battery and display unit.
3. Check for reversed polarity on the power connections.
4. Verify battery has a minimum voltage of 6 Volts.

Display resets or goes OFF when starting engine.

1. Check display supply wires are connected properly to battery.
2. Verify battery is charged properly.
3. Check battery for efficient starter current.

Display has no backlight.

Contact your Supra service center.

Display has no keypad backlight.

Contact your Supra service center.